



Recessed Perception Fixture Installation Guide

1. Measure and cut a recess in the mounting surface to match the width of the Perception fixture body (excluding the flanges), equal to 0.985 in. (25 mm).




2. Prepare remote drivers and make any necessary electrical connections between the fixture and remote junction boxes through the recess. **BE SURE** that power input cables **ARE NOT** supporting the weight of the fixture before completing installation.


• **IF YOUR PENDANT** has an **ASYMMETRIC LENS** be sure to check which canopy will feed the power supply to properly orient your fixture.



3. Bring the fixture up to the recess with the spring clips fully extended and fit them through the recess.



4. Push the fixture into the recess until the spring clips snap closed on the opposite side of the surface.



5. Fixture installation complete.

