


### Perception Pendant Series Mud-in Fixture Installation Guide


1. Measure and cut a recess in the drywall surface 0.98 in. (24.9 mm) wide by 0.74 in. (18.8 mm) deep.




2. Prepare remote drivers and make any necessary electrical connections between the fixture and remote junction boxes through the recess. Be sure that power input cables **DO NOT** support the weight of the fixture before completed installation.

• IF YOUR FIXTURE has an **ASYMMETRIC LENS** be sure to check which end will feed the power supply to properly orient your fixture.


Place the fixture into the recess and secure it by fastening screws through the slots on the flanges.



3. Carefully place painter's tape over the fixture lens to protect it from spackle. Be sure to completely cover the lens. Use multiple strips of tape if necessary.



4. Apply drywall mesh tape between the flanges and drywall as necessary. Plaster (mud-in) over the flanges and screws up to the lip of the channel to create a seamless fixture.



5. Finish drywall surface (by sanding or smoothing) as desired. When finished, remove the protective painter's tape from the lens. Installation complete.

