



***NOTE:** End caps each add 2 mm to length of the fixture.

1.




Measure and mark the desired location of the mounting clips.

2.




Cut channel and lens to desired (equal) lengths.

3.




Clean the inside surface of the channel of dust and debris with rubbing alcohol. Dry.

4.




Apply RibbonLyte. Make all necessary electrical connections.

5.




Attach lens by sliding or snapping into place.

6.




Mount fixture by screwing through middle of channel mounting section.

7.




Attach end caps if needed. If using raised round lens, use rounded end cap (right).

8.



Install large cover to front of channel. Attach cover to bottom lip of channel, then click into top lip.

9.



Fixture installation complete.

***NOTE:** DO NOT try to remove large cover by force. Use flat tool to carefully remove cover (from the top out toward you).

***NOTE:** When using couplers, attach couplers to surface first, then attach main channel to couplers.