FLEXIBLE BACKLYTE INSTALLATION GUIDE


Tech Support: (+1) 212 629 6830 *301 Tech@GENLEDBrands.com

WARNINGS



TRIMMING AND INPUT CORNERS

* The Flexible BackLyte can be trimmed into the desired shape along the dotted lines and be powered up with any one of the 4 power input corners. Any of the 4 power input corners (outlined in green) can supply power to the entire sheet of Flexible BackLyte. See examples below:






FLEXIBLE BACKLYTE INSTALLATION GUIDE


Tech Support: (+1) 212 629 6830 *301 Tech@GENLEDBrands.com

STANDARD INSTALLATION


1. Determine installation location.




Place Flexible BackLyte in desired location.Screw through the screw holes on Flexible BackLyte to secure it in place.




3. Connect power supply to Flexible BackLyte to complete installation.



CUSTOM INSTALLATION




2. Trim Flexible BackLyte along the dotted lines to desired shape.






3. Place Flexible BackLyte in desired location. Screw through the screw holes on Flexible BackLyte to secure it in place.





4. Connect power supply to Flexible BackLyte.

Maximum number of daisy chained fixtures is 8.



REV.29APR2021