



Perception Pendant, Surface and Recessed Fixture Coupler Installation Guide

1. Check that applicable fixtures do not have end caps. Slide the coupler into the slot on the top of one of the Perception fixtures so that half of the coupler is still exposed.



2. (a) Fasten the inserted half of the coupler to the first fixture with a screw. (b) Slide the other Perception fixture onto the exposed half of the coupler.



3. Ensure that the two fixtures are aligned and fully joined to avoid any gaps that could cause light leaks. (a) Fasten second fixture to the coupler with a screw. (b) Installation complete.

