



1.





Measure and mark the desired location of the corner mounting clips. Drill a pilot hole for mounting clip fasteners. 2.



Screw the fasteners through the mounting clips to fix them in place on the surface.









Cut channel and lens to desired (equal) lengths.






Clean the inside surface of the channel of dust and debris with rubbing alcohol. Dry.



Apply RibbonLyte and make all necessary electrical connections. (Run through end caps as needed.)




Attach lens by sliding or snapping into place. Attach end caps. See next step for mounting clip instruction.





With flexible mounting clips, align one edge first, then push down second edge to snap into place. With regular mounting plate, align the channel above the mounting clips and push down to snap into place.





Fixture installation complete.

*NOTE: End caps are marked with a spot to bore holes for power supply. Each end cap adds 2 mm to length of fixture.

*NOTE: Due to the shape of this profile, we DO NOT recommend using liquid adhesive.

REV.28JUN2021