





1. Tilt the fixture top to one side and position the fixture at the desired location.




2. Screw in the screws through the screw holes on the tiltable stands.



3. Tilt the fixture top to the other side and screw in the screws through the screw holes on the tiltable stands same as Step 2.




4. Connect to power supply and to additional fixture if desire to complete the installation.






Note: Mounting arms need to be installed with proper damping hardware in extreme vibration environments


1. Use proper screws (screw size up to 1/4" or M6.5) to mount one extension arm onto the wall.




2. Mount the other arm onto the wall. Make sure the distance (D) is the same as the tiltable stands distance (D) on the fixture.



3. Use L-Key (M4) to loosen the hex socket screws and adjust the inner channels to the desired arm length. Then tighten the screws to secure the inner channels.



4. Loosen the set screws and adjust the position of the tiltable stand if it's misaligned to the extension arms.



5. Secure the fixture on the pair of extension arms by fastening the screws in the tiltable stand to the extension arms. (See Step 1-4 for reference)

