




1. Measure and mark the desired location of the mounting clips. Drill pilot holes for mounting clips. Affix the mounting clips to the surface with screws.




2. Clean the inside surface of the channel of dust and debris with rubbing alcohol. Dry, then apply RibbonLyte. Make all necessary electrical connections. (Note: For end feed, be sure to thread wire through end cap but do not attach end cap to channel yet.)




3. Snap lens into place.



4. Attach end caps.



5. Pivot the top section of the mounting clips so they are slightly open. Align the channel straight above the base of the mounting clips and lower to the point of contact, then pivot each mounting clip closed to secure fixture in place.



6. AS24R fixture installation complete.

